

FP Range 2-14 Zone Fire Alarm Control Panels

Installation Instructions

THIS EQUIPMENT MUST ONLY BE INSTALLED AND MAINTAINED BY A SUITABLY SKILLED AND TECHNICALLY COMPETENT PERSON. THIS EQUIPMENT IS A PIECE OF CLASS 1 EQUIPMENT AND MUST BE EARTHED. DO NOT CHANGE ANY PANEL CONNECTIONS WITH THE PANEL'S POWER APPLIED (MAINS OR BATTERY POWER).



INSTALLATION PROCEDURE

All cables must be installed in accordance with all applicable national, regional or local standards. In the UK this is BS 7671 IEE Wiring Regulations and BS 5839-1, Fire detection and alarm systems for buildings: Code of practice for system design, installation and maintenance. Fire resistant, screened cable should be used throughout the installation and Mains wiring should be segregated from extra low voltage field wiring.

For PERMANENTLY CONNECTED equipment, a readily accessible disconnect device shall be incorporated external to the equipment.

The general requirement for the Mains supply to the panel is fixed wiring, using 3 core cable, (no less than 1mm² and no more than 2.5mm²), or a suitable three conductor system fed from an isolating switched fused spur, fused at 3A. The Mains supply must be exclusive to the panel.

HINT. As an alternative to a switched fused spur, a double pole isolating device (B) may be used in the Mains feed from the Main Distribution Board (A) to the panel (C), providing it meets the appropriate wiring regulations – see Fig 1.



- Remove the panel's lid (disconnect attached loom connector).
- Fit the panel's back box securely to a wall using the mounting holes provided and suitable screw fixings. Remove required number of knockouts and fill holes with good quality cable glands – see Fig 2.
- Gland field cables and terminate all screens to the panel.



CAUTION: DO NOT use an insulation tester (Megger) with any electronic devices connected as the test voltage will totally destroy the devices.

- Test field cables and ensure they are fault-free, i.e. check continuity of cable runs (including screens).
- Connect external Mains cable to the panel's fused Mains terminal block (with Mains isolated) – see Fig 2.


CAUTION: RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE. DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS.

Also, if the battery leads are connected in reverse, the battery fuse (F1) will blow which may damage the panel and invalidate the warranty.


- Position and connect the panel's two, good quality, internal 12V sealed lead acid batteries (with battery supply isolated) – see Fig 3 & Fig 4.
- Connect zone circuits to the panel – see Fig 5.
- Connect sounder circuits to the panel – see Fig 5.
- Connect ancillary connections to the panel.
- Refit the panel's lid (re-connect loom connector).
- Apply Mains and battery supply to power up the panel.
- The panel should be in normal mode. If not, investigate and rectify any faults indicated on the panel.
- Finally, test the panel – see pages 2 & 3.




TYPICAL ZONE CIRCUIT - Call points wired before detectors
- Detector base diodes not needed.



TYPICAL ZONE CIRCUIT - With mixed order call points and detectors
- Detector bases fitted with continuity diodes and negative connection linked out.



TYPICAL SOUNDER CIRCUITS
Only use polarised sounders!



EOLR = End of Line Resistor (6k8Ω, 0.25W) - supplied
CPR = Call Point Resistor (470 - 680Ω, 0.5W) - supplied with call point

TESTING THE PANEL

When testing the panel with the panel lid open, always isolate the Mains and disconnect the batteries. The panel can be tested before connecting field wiring. If testing before installation, ensure the end-of-line resistors are fitted in the panel's sounder and detector terminal blocks.

Position and connect two, good quality, 12V batteries in the panel as shown in Fig 3 and Fig 4 (page 1). When the batteries are connected, the POWER SUPPLY FAULT indicator will light and the warning beeper will sound. Connect the Mains wiring and turn the Mains supply on. The MAINS ON indicator will light, the POWER SUPPLY FAULT indicator will go out and the warning beeper will silence (providing the batteries are not flat).

WITH THE KEYSWITCH AT NORMAL POSITION

The MAINS ON indicator is lit. No other indicators are lit. No sounders are active. The pushbuttons are inoperative.

TURN THE KEYSWITCH TO ARM CONTROLS POSITION

Note: None of the panel's pushbuttons are operative unless the keyswitch is in the ARM CONTROLS position.

Press RESET/RESOUND/TEST ZONE LAMPS. The ZONE FIRE and ZONE FAULT indicators light and the warning beeper will sound. The MAINS ON indicator will remain lit. All the other indicators will NOT light. Release the pushbutton and the panel will return to normal.

TEST THE POWER SUPPLY MONITORING CIRCUIT

Switch off the Mains. The POWER SUPPLY FAULT indicator will light, the MAINS ON indicator will extinguish, and the warning beeper will sound. Press SILENCE FAULT SOUNDERS and the warning beeper will silence but the POWER SUPPLY FAULT indicator will remain lit. Reconnect the Mains and the panel will revert to normal. Disconnect the battery. The POWER SUPPLY FAULT indicator will light and the warning beeper will sound. Reconnect the battery and after a short time the panel will revert to normal (i.e. only the MAINS ON indicator light on). Note: This test should be carried out with a set of new and fully charged batteries – deteriorated cells will show a fault even when connected and charged up.

TEST THE SOUNDER MONITORING CIRCUITS

DO NOT carry out this test with the ZONE FIRE indicators lit as sounder fuses F2 & F3 could blow. Ensure the end-of-line resistor is connected across each of the sounder circuits on terminals 5 & 6, 7 & 8. Short the sounder terminals 5 & 6. The SOUNDER FAULT indicator will light and the warning beeper will sound.

Press SILENCE FAULT SOUNDERS and the warning beeper will silence but the SOUNDER FAULT indicator will stay on. Remove the short and the panel will revert to normal. Open circuit the sounder terminals 5 & 6 by disconnecting one leg of the end-of-line resistor. The SOUNDER FAULT indicator will light and the warning beeper will sound. Press SILENCE FAULT SOUNDERS and the warning beeper will silence but the SOUNDER FAULT indicator will stay on. Remake the circuit and the panel will revert to normal.

Repeat the test for the other sounder circuit via terminals 7 & 8.

TEST THE DETECTOR MONITORING CIRCUITS

Make sure an end-of-line device (EOLD) is connected across each pair of detector terminals (9 & 10, 11 & 12, etc.). The EOLD would either be a 6.8k Ω resistor or Electronic Monitoring Unit (EMU) and associated Panel Module, depending on the installation. Refer to Fig 5 (page 1) & EMU instructions for connections.

The following four conditions can exist on the detector monitoring circuits:

- 1. Normal Condition:** Current flows round the detector loop via the EOLD to monitor the wiring.
- 2. Open Circuit Fault:** The wiring is broken at some point and the monitoring current cannot flow through the EOLD.
- 3. Short Circuit Fault:** A short circuit exists at some point and too much monitoring current flows.
- 4. Fire Condition:** A partial short exists and the monitoring current increases but not enough to show a short circuit fault. Most smoke detectors make a partial short when they are triggered but manual call points and other normally open switches need to have 470 or 680 Ω resistors connected in series in order to give a partial short. (Check - Resistor may be built into the Call Point - see Fig 5, page 1.)

OPEN CIRCUIT FAULT TEST

Open circuit the zone circuit terminals 9 & 10 by disconnecting one wire of the EOLD. The ZONE 1 FAULT indicator and internal ZONE 1 OPEN CIRCUIT FAULT indicator will light. The warning beeper will also sound. Press SILENCE FAULT SOUNDERS and the warning beeper will silence but the indicators will stay on. Reconnect the EOLD and the panel will revert to normal.

SHORT CIRCUIT FAULT TEST

Short circuit the zone circuit terminals 9 & 10. The ZONE 1 FAULT indicator and internal ZONE 1 SHORT CIRCUIT FAULT indicator will light. The warning beeper will also sound. Press SILENCE FAULT SOUNDERS and the warning beeper will silence but the indicators will stay on. Remove the short and the panel will revert to normal. Repeat the test for the other zone circuit via terminals 11 & 12.

FIRE CONDITION

Simulate a Fire condition by connecting and activating a Call Point, or by fitting a 470 to 680 Ω resistor across terminals 9 & 10. The sounder output relay will operate, ZONE 1 FIRE indicator lights and the warning beeper sounds. Press SILENCE ALARM SOUNDERS. The sounder outputs return to normal but the ZONE 1 FIRE indicator will still be lit and the warning beeper will still sound. Press RESET/RESOUND/TEST ZONE LAMPS and the panel will go back into alarm as the Fire condition is still present. Remove the Fire condition. Press SILENCE ALARM SOUNDERS, then RESET/RESOUND/TEST ZONE LAMPS and the panel reverts to normal. Repeat test for the other zone terminals.

Notes:


- 1) Pressing RESET/RESOUND/TEST ZONE LAMPS when in the unsilenced Fire condition (i.e. Sounder Outputs energised) has no effect. The sounders **MUST** be Silenced first before Reset is active.
- 2) When the Alarm Sounders are silenced, the warning beeper will sound and cannot be silenced.
- 3) Resetting the system from the Silenced Fire state with the fire condition still existing will retrigger the alarm.

EVACUATE

Press EVACUATE. The Sounder Outputs will operate, the ZONE FIRE indicators will light and the warning beeper will sound. Press SILENCE ALARM SOUNDERS and the Sounder Outputs will return to the normal state. The ZONE FIRE indicators will still be lit and the warning beeper will still be active. Press RESET/RESOUND/TEST ZONE LAMPS to return the panel to normal state.

TESTING THE SYSTEM

Check each detector and sounder on the system, and check the functions of the panel. Check all circuits for open and short circuit faults. If continuity diodes are fitted remove each head in turn and check that call points are still operative. When testing is complete return the keyswitch to NORMAL position.

ANCILLARY FACILITIES (Links and internal features are shown in Fig 6 below)**ENGINEERS TEST (NON-LATCH TEST) FACILITY**

This range of panels has a non-latching test facility which allows manual call points and smoke detectors to be tested and reset automatically. To set this facility move the link marked 'PL1' on the main PCB from the lower to the upper position. The adjacent indicator will light, the warning beeper will sound and cannot be silenced. When an alarm condition is caused the alarm sounders will operate for about half a second and will silence for three seconds before resounding. This will continue until the cause of the alarm is removed by the smoke clearing from a detector or the call point being reset. When testing is complete, replace the link to the lower position.

ZONE ISOLATION FACILITY

Each Detector Zone can be isolated individually by moving the links (PL2/PL4) from the lower to the upper position. The adjacent indicator and relevant ZONE FAULT indicator will light to show that the zone is isolated. The warning buzzer will sound and cannot be silenced. When testing is complete, replace the link to the lower position.

TO REVERT TO SHORT CIRCUIT = FIRE

This facility overrides the short circuit fault monitoring for each zone and allows the panel to be used on installations which do not have Call Point Resistors fitted. It produces a short circuit Fire condition when activated. To enable this facility cut the wire links (LK1/LK2) on the main PCB.

AUXILIARY EXPANSION PLUG (PL10)

This plug connector offers facilities for driving Repeater Panels, Fire and Fault relays and a "Class Change" input. These facilities require various ancillary devices to be added to the panel (not included).

AUX 24V +VE

This output is a regulated, unmonitored, output fused at 1A (F4), available from terminal 1 in the panel's base connections. With link 'PL3' on the main PCB linked in position furthest from the F4 fuse this output is continuous. If linked nearest to the F4 fuse then the output is present when the panel is normal but is switched off when the relay is activated. This facility can be used to provide a fail-safe output via AUX 24V, that "switches off" when the sounders are activated, or if power to the panel fails.

Note: Any load provided by this output increases the quiescent drain on the panel's supply which in turn affects the stand-by time of the system. It is not intended to supply door release systems.

VOLTAGE FREE RELAY CONTACTS

These single pole relay outputs available via terminals 2 (normally closed), 3 (common), and 4 (normally open) in the panel's base connections change over when the sounders are activated. They must not be used to switch Mains potentials, the contacts being rated at 30Vdc and 1.0A.

FP RANGE TECHNICAL SPECIFICATION

CONTROLS

EXTERNAL PUSHBUTTONS (KEYSWITCH ACTIVATED)

- RESET / RESOUND / TEST ZONE LAMPS
- SILENCE ALARM SOUNDERS ■ EVACUATE
- SILENCE FAULT SOUNDERS

INTERNAL

- Engineer Detector Test
- Zone Isolate
- Revert to short circuit = fire (no resistors in Call Points)

EXTERNAL INDICATORS

- SOUNDER FAULT ■ POWER SUPPLY FAULT
- MAINS ON ■ ZONE FIRE ■ ZONE FAULT

INTERNAL INDICATORS

- OPEN CIRCUIT ZONE FAULT ■ SHORT CIRCUIT ZONE FAULT
- ZONE ISOLATED ■ ENGINEER TEST SELECTED

OUTPUTS

- 2 sounder circuits (Alarm relay contacts can be obtained by connecting an RLP-24 relay to a sounder circuit).
- Ancillary connections for expansion modules will allow the following: (1) Repeater Panels; (2) Multiple sounder outputs; (3) Connection to Landlord's Panel.

■ Zone Isolate			FP 2 (0.8 A SUPPLY)			FP 4 / 6 (1.4 A SUPPLY)			FP 8 / 10 / 12 / 14 (3.0 A SUPPLY)		
■ Revert to short circuit = fire (no resistors in Call Points)			Part No. FF382-2			Part Nos. FF384-2 / FF386-2			Part Nos. FF388-2 / FF390-2 / FF392-2 / FF394-2		
POWER SPECIFICATION											
MAINS SUPPLY VOLTAGE	FREQUENCY	RATED CURRENT	220-230 Va.c.	50/60 Hz	185 mA	220-230 Va.c.	50/60 Hz	330 mA	220-230 Va.c.	50/60 Hz	700 mA
INTERNAL POWER SUPPLY			27 Vd.c. nominal								
TOTAL OUTPUT CURRENT LIMITED TO			800 mA			1400 mA			3000 mA		
AUXILIARY POWER OUTPUT			27 Vd.c. nominal								
MAINS SUPPLY MONITORED FOR FAILURE			YES								
BATTERY CHARGER MONITORED FOR FAILURE			YES								
BATTERIES MONITORED FOR DISCONNECTION / FAILURE			YES								
DETECTOR CIRCUIT SPECIFICATION											
NUMBER OF CIRCUITS			2			4 or 6			8, 10, 12 or 14		
LINE FAULT MONITORED FOR OPEN CIRCUIT			YES								
LINE FAULT MONITORED FOR SHORT CIRCUIT			YES (can be disabled)								
LINE FAULT MONITORED FOR DETECTOR REMOVAL			Yes, if End of Line Monitoring Unit fitted in place of End of Line Resistor								
END OF LINE RESISTOR (SUPPLIED)			6800 Ω, 5% tolerance, 0.25 W (colour code - blue, grey, red, gold)								
DETECTOR CONTINUITY DIODES			Silicon 1N4001 or Schottky type (required if End of Line Monitoring Unit fitted)								
CALL POINT RESISTOR (NOT SUPPLIED)			470 to 680 Ω, 0.5 W								
MAXIMUM NUMBER OF SMOKE/HEAT DETECTORS PER ZONE			20 (maximum detector current = 2 mA)								
MAXIMUM NUMBER OF MANUAL CALL POINTS PER ZONE			No limit								
SOUNDER CIRCUIT SPECIFICATION											
NUMBER OF CIRCUITS			2								
END OF LINE RESISTOR (SUPPLIED)			6800 Ω, 5% tolerance, 0.25 W (colour code - blue, grey, red, gold)								
LINE FAULT MONITORED FOR OPEN CIRCUIT			YES								
LINE FAULT MONITORED FOR SHORT CIRCUIT			YES								
OUTPUTS FUSED AT			1 A			1 A			1.6 A		
MAXIMUM TOTAL OUTPUT CURRENT (ALL OUTPUTS)			800 mA			1400 mA			3000 mA		
MAXIMUM NO OF BELLS @ 25 mA EACH			32			56			120		
MAXIMUM NO OF ELECTRONIC SOUNDERS @ 20 mA EACH			40			70			150		
AUXILIARY RELAY CONTACTS (DO NOT CONNECT MAINS VOLTAGES)			1 A 30 Vd.c. max. Voltage-Free								
FUSES - ALL FUSES COMPLIANT TO IEC (EN 60127 PT2)											
MAINS TERMINAL BLOCK			200 mA T 20 mm			400 mA T 20 mm			630 mA T 20 mm		
SOUNDER OUTPUTS (F2, F3)			1 A F 20 mm			1 A F 20 mm			1.6 A F 20 mm		
AUXILIARY OUTPUT (F4)			1 A F 20 mm								
BATTERY FUSE (F1)			1.6 A F 20 mm			1.6 A F 20 mm			3 A F 20 mm		
DOOR RETAINING MAGNETS			DO NOT USE PANEL POWER SUPPLY AS YOU WILL DRASTICALLY REDUCE BATTERY STAND-BY TIME								
CONNECTION BLOCK											
LARGEST ACCEPTABLE CONDUCTOR SIZE			2.5 mm ²								
SMALLEST ACCEPTABLE CONDUCTOR SIZE			0.75 mm ²								
PHYSICAL											
ENCLOSURE (WIDTH x HEIGHT x DEPTH)			322 x 267 x 92 mm			405 x 267 x 92 mm			521 x 334 x 140 mm		
WEIGHT (WITHOUT BATTERIES)			4.3 kg			5.0 kg			9.2 kg		
IP RATING (to EN 60529)			IP30 (when correctly installed)								
ANCILLARIES (Individual datasheets available on request)											
REPEATER PANELS (available in 10 and 20 Zone versions)			Up to 3 Repeaters per control panel. Wiring=5 cores plus one per zone. Maximum cable length=200 metres. Facilities = common fault light; one fire light per zone; warning buzzer; test button (tests lights, buzzer & interconnecting wiring).								
4 ZONE MONITORED SOUNDER EXTENDER KITS			Connects to existing sounder circuits to provide four additional monitored sounder circuits.								
RLP-24 5 A RELAY ON PLATE (Fits single gang back boxes)			General purpose polarised and suppressed relay for use with 24 volt fire alarm systems. Can switch Mains loads.								
FLUSH BEZELS			Available in two different sizes to fit all variants of master panel and repeater metalwork, except two zone.								
ENVIRONMENTAL											
OPERATING TEMPERATURE			-10°C to +40°C								
HUMIDITY			5% to 95% RH (non-condensing)								

QUIESCENT CURRENT / BATTERY STAND-BY TIME (HRS)

NUMBER OF ZONES	2	4	6	8	10	12	14
QUIESCENT CURRENT (mA)	40	50	60	70	80	90	100
MAX LOAD CURRENT (A)	0.80	1.40	1.40	3.00	3.00	3.00	3.00
STAND-BY (HRS) BATT. SIZE 2.0 Ah	40	26	-	-	-	-	-
STAND-BY (HRS) BATT. SIZE 2.6 Ah	55	38	32	-	-	-	-
STAND-BY (HRS) BATT. SIZE 4.0 Ah	90	66	55	36	31	28	25
STAND-BY (HRS) BATT. SIZE 6.0 Ah	-	106	88	64	56	50	45
STAND-BY (HRS) BATT. SIZE 10.0 Ah	-	-	-	121	106	94	85

The quiescent currents listed are for the following conditions:

Mains Supply failed, fault beeper muted, no aux. output connections, EOL devices and resistors only fitted to detector and sounder loops.

The battery stand-by times are guidelines only based on the above conditions and a full sounder load for 30 minutes. Additional loads that increase the quiescent current in the normal state must be considered when calculating stand-by time. The fault beeper being active will add 10 mA and reduced sounder loads will increase the stand-by time. Batteries in poor condition greatly reduce stand-by time.

E&OE. No responsibility can be accepted by the manufacturer or distributors of this equipment for any misinterpretation of this instruction, or for the compliance of the system as a whole. The manufacturers policy is one of continuous improvement and we reserve the right to make changes to product specifications at our discretion and without prior notice.